



[PRODUCTS](#)   [SUPPORT](#)   [MEDIA / EVENTS](#)   [PRODUCT REGISTRATION](#)

[WHERE TO BUY](#) [Home](#) > [Support](#) > [Technical Support Knowledge Base](#) > Knowledge Base Article

## Knowledge Base Article 616A196381

### Issue

How do I activate the cross-band repeat function on my 2720H?

### Resolution

To activate the cross-band repeat function:

Press and hold the LOW and DUP buttons, then press and hold the SET/LOCK button on the front of the radio for 2 seconds. You will see the letter "L" flashing in the channel location for each band.

To cancel the cross-band repeat function:

Press and hold the SET/LOCK button for 2 seconds.

### Category

Amateur : Mobile Dual / Tri Band : 2720H